

This guide provides general installation direction. Every shower setup may vary. The installer is responsible for confirming the connection is secure and leak-free before use. Review all installation materials before beginning any work.

1 Confirm Kit + Inspect Components

Verify required parts:

- S1 Shower Handle Filter

Inspect before installation:

- No cracks or damage on the filter body
- Threads are clean and undamaged

Do not proceed if anything is missing or damaged.

2 Prepare the Shower

Shut down:

- Turn off the shower completely
- Confirm the installation area is dry enough to work safely

3 Remove the Existing Shower Handle

Removal:

- Unscrew the existing shower handle by rotating it counterclockwise
- Remove it carefully from the connection point
- Inspect the connection point and clean away any debris if needed

4 Install the S1 Shower Handle Filter

Installation:

- Screw the S1 Shower Handle Filter onto the connection point
- Rotate clockwise until snug (do not overtighten)

5 Start-Up, Leak Check, Flush

Start-up:

- Turn the shower back on slowly
- Allow water to flow through the S1 Shower Handle Filter

Leak check:

- Inspect the connection point for leaks
- If needed, turn the shower off and gently tighten the connection

Flush:

- Let water run through the filter briefly before regular use

Final verification:

- Confirm no leaks
- Confirm normal water flow
- Confirm the filter is secure

Installation Complete — The S1 Shower Handle Filter is now installed and ready to provide cleaner, filtered water every time you shower.