

This guide provides general filter replacement direction. Every home's plumbing or fixture setup may vary. Before beginning, confirm the water is turned off and the area is prepared for a clean replacement. After replacement, slowly restore water flow and check carefully for leaks before regular use.

1 Confirm Replacement Parts + Prepare Area

Verify required parts:

- P1 under-sink replacement cartridge

Inspect before replacement:

- Replacement cartridge is clean and undamaged
- Filter head, centerpiece, and cartridge body are accessible
- Cold water shutoff can be operated

Do not begin replacement if the replacement cartridge is missing, damaged, or incompatible.

2 Shut Off Cold Water

Shut down:

- Turn off the cold water line under the sink
- Open the faucet briefly to relieve pressure

3 Remove the Centerpiece + Cartridge Body

Disconnect from the head:

- Facing the filter, grip the centerpiece and turn it a quarter turn counterclockwise
- Pull the assembly straight down — the centerpiece and cartridge body will come out together
- Keep the assembly upright where possible to avoid spilling residual water

4 Replace the Cartridge

Separate the centerpiece from the cartridge body:

- Turn the centerpiece counterclockwise to unscrew it from the cartridge body
- Remove the old cartridge from the cartridge body
- Insert the new cartridge into the cartridge body

Reassemble:

- Screw the centerpiece back onto the cartridge body by turning clockwise until snug
- Confirm the centerpiece is properly seated and aligned

5 Reattach to the Head

Reconnect the assembly:

- Lift the centerpiece and cartridge body back up into the head
- Turn the centerpiece a quarter turn clockwise until it locks into place
- You should feel the assembly lock securely in place

6 Restore Water + Leak Check

Start-up:

- Slowly turn the cold water back on
- Run water through the filter before regular use

Leak check:

- Inspect the filter head, housing, and nearby connections
- Confirm there are no leaks
- Confirm normal water flow at the faucet

Replacement Complete — The P1 Under-Sink Filter cartridge has been replaced and is ready for use.